

DIGIMERGE

Product FAQ

FAQ No: FAQ-080811-06

Date: August 11, 2008

Product: D17800

To Record on Demand on a D17800 Series System

To Turn Continuous and Motion Record OFF

- Press **Setup**
- Select *Record Menu*
- Scroll down to *Continuous/Motion Setup*
- Press **Enter**



- Use the right arrow button to scroll to *Schedule*
- Press **Enter** three times
- Press the **Left arrow** to highlight the first row
- Press the **Up arrow** to highlight the all the bottom channels
- Press **Enter** once, a box will pop-up
- Scroll up to *None* and press **Enter**. A checkmark will come up beside *None*
- Press **Return** four times and a box will come up "*Configuration has been changed. Do you want to save the configuration? OK or CANCEL*"
- Press **Enter** on "OK"
- Press **Return** to go back to the main screen.

Digimerge Technologies Inc.

300 Alden Road • Markham • Ontario • Canada • L3R4C1
tel: (905)946-8477 • fax: (905)947-0138


To Turn On ALARM Recording for On Demand Record

Turning ON Alarm Schedule

- Press **Setup**
- Select *Record Menu*
- Scroll down to *Alarm Setup*
- Press **Enter**
- Use the **right arrow** button to scroll to *Schedule*
- Press **Enter** three times
- Press the **Left arrow** to highlight the first row
- Press the **Up arrow** to highlight the all the bottom channels.
- Press **Enter**. All the boxes should change to a light blue colour.
- Press **Return** four times and a box will come up "*Configuration has been changed. Do you want to save the configuration? OK or CANCEL*"
- Press **Enter** on "OK"
- Press **Return** to go back to the main screen.

Setting up the Alarm Inputs

- Connect the wires to the back of the unit.
- Press **Setup**
- Select *System Setup*
- Select *Event/Sensor*
- Scroll down to *Alarm IN*



- Press **Enter** and scroll to the Alarm number you have Selected.
- Press **Enter** and using the **Up** and **down arrows** change the Operation from Disable to Enable.
- Press **Enter**
- Scroll right to Type. Select the Type N/O or N/C
- Press **Enter**

- Scroll down to *Apply* and press **Enter**
- Press **Return** four times to get out of the Alarm menu

Each camera should have a green box on the top right hand corner. When the Alarm is triggered it will turn to a red box with an **A** beside it.